

Punkt/Line	START		SLUTT	
	Breddegr.	Lengdegr.	Breddegr.	Lengdegr.
Fiskeridir.	60°33,806'	5°21,181'	°'	°'
Midtpunkt	60°33,628'	5°21,457'	°'	°'
NV	60°33,630'	5°21,441'	°'	°'
NØ	60°33,635'	5°21,468'	°'	°'
SØ	60°33,625'	5°21,474'	°'	°'
SV	60°33,621'	5°21,446'	°'	°'
F1	60°33,630'	5°21,441'	60°33,702'	5°20,670'
F2	60°33,630'	5°21,441'	60°33,768'	5°20,928'
F3	60°33,635'	5°21,468'	60°33,858'	5°21,908'
F4	60°33,635'	5°21,468'	60°33,851'	5°22,077'
F5	60°33,625'	5°21,474'	60°33,503'	5°22,264'
F6	60°33,625'	5°21,474'	60°33,427'	5°21,904'
F7	60°33,621'	5°21,446'	60°33,394'	5°21,294'
F8	60°33,621'	5°21,446'	60°33,395'	5°20,972'

	UTM	UTM
Fiskeridir	<input type="text"/>	<input type="text"/>
	°' N	°' Ø
	<input type="text"/>	<input type="text"/>

Strømmåler