




Tegnforklaring VA

○ Kum	• Slamavskiller	➡ Reduksjonsventil
• Hydrant	Stengeventil	→ Fallretning
• Brannkum	⊠ Sluk	> Pumperetning

— Vassleiding
- - - Overvatn
- - - Spillvatn

Tegn. anna

• • • Grensepkt.
— Grense
— Ope vatn