

### Service datoer for avløpsreosanlegg:

B = Bestilt anlegg - L = Levert anlegg - M = Montert anlegg - S = Service

T = Slamtømming - F = Feilsøking - E = Ekstra besøk - K = 1 kanne kjemikalie

Ruter: [Slamtømming](#): [Avvik](#):

#### LINDÅS 8-4B

Type	Navn	Kundenr.:	2003	2004	2005	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015	2016	2017	2018
BF1	Bruntlandsåsen VEL RA v / Øvvind Hauge 5955 Lindås	1631	L: 21/1 M: 21/5 E: 20/6  E: 7/8	S: 19/3		E: 4/10	T: 18/5 S,K2: 3/10	S: 8/2 E;2K: 7/4 S: 15/5 S: 10/7 S,2K: 9/10 T: 18/11	S: 15/1 S: 3/4 S: 25/6 S,K:18/11	S:23/2 S: 25/5 S,2K:27/8 S:9/8 S,2K:16/11	S,2K;16/2 S,2K;9/5 S;9/8 S;20/12	S:21/3 S;20/6 S;3/10	S;14/1 S;22/2 E;3/4 E,2K;8/4	S:28/2 S,K;19/6 S;15/10	S;8/1 E;20/1 S;22/4 S,2K;7/7 S;3/11	S;21/12-15 S;11/3 S,2K;8/8	S,2K;12/1 S;4/4 T: 16/5 S,K: 13/7 S;23/11	S,K;2/2 S;23/5 T: 16/5 S,K;24/9 T;1/10 S;13/11